






[!\[\]\(c8d96c8885d3000a912c2582004aed63_img.jpg\) Back](#)



[← Back](#)

Contrast Saturation
Sharpness Color tone




Press the <JUMP> button to see the settings.

← Back

Adjusted setting

Default setting



← Back

Custom Function 02

Noise reduction

1:Auto noise reduction

01 02 03 04 05 06 07 08 09 10

0 0 0 0 0 0 0 0 0 0

11 12 13 14 15 16 17 18 19 20 00

0 0 0 0 0 0 0 0 0 0 0

← Back

Select folder

101EOS5D	32
102EOS5D	2
103EOS5D	17
104EOS5D	13

Create folder

← Back



JUMP



Auto power off

Auto rotate

LCD brightness


Date/Time 08

File numbering ▶ Continuous

Select folder Auto reset

Language Manual reset

← Back




[← Back](#)


プレシジョンマット




スーパープレシジョンマット



[!\[\]\(71ceb62b681518c82e95d615e7265d66_img.jpg\) Back](#)







[← Back](#)




[← Back](#)



[← Back](#)



[← Back](#)



Shooting information




Camera settings


← Back




[← Back](#)




Digital control circuit board



Camera control circuit board



Power source circuit board



Display control circuit board

[← Back](#)